



STEP 4

Choose which side you would like your chaise to be on (left hand or right hand facing) then align your brackets and push down firmly to connect.




STEP 5

Connect the Arms (D) to the Chaise (B) and the Seat Section (A) by aligning the brackets as shown and then push down firmly to connect.



STEP 6


Place the Back Cushion (G) and Small Cushions (H) on the sofa bed - this is now ready to use.



USING YOUR SOFA BED

Carefully, pull the Pop Up Section out using the handle, then gripping the edge of the drawer to open it out fully. Use the handle to pull the Pop Up Section up and gently push it into place. You may need to adjust the placement of the Pop Up section, by pushing it towards the Chaise Section, should there be a gap.

FABRIC CONTENT
MAIN FABRIC 100% POLYESTER
OTHER FABRIC (VISIBLE)
NON-WOVEN FABRIC 100% POLYESTER



KY479 CORNER SOFA BED

Thank you for your purchase. The following care instructions will allow you to make the most of your sofa bed; helping to prolong the look and life of it by preventing wear and damage.

IMPORTANT INFORMATION

PLEASE ENSURE YOU READ THIS LEAFLET BEFORE USING YOUR SOFA BED. DO NOT DISCARD OF ANY PACKAGING UNTIL YOU HAVE CHECKED THE PRODUCT THOROUGHLY.

CARING FOR YOUR SOFA BED

- Pre-brush fabric with a soft brush and then gently vacuum.
- Plump any accent/removable cushions regularly to prevent them becoming mis-shaped or flat.
- Use a microfibre cloth to remove dust from wooden surfaces.
- In the event of a spill or stain, use specialist upholstery cleaner or cleaning services.





SUNLIGHT AND HEAT DAMAGE

- Avoid contact with direct sunlight. If needed, move items or change their position to avoid the same area being exposed to repeated sunlight/heat.
- Do not place your sofa bed close to fire places and/or radiators.
- Hot objects such as mugs/plates can permanently mark the fabric and wood, avoid placing these on the sofa bed.

SAFETY WARNINGS

- Do not allow children or pets to climb or jump on the sofa bed.
- Avoid contact with sharp objects such as buckles, toys and jewellery as these can easily snag, tear and/or pull the fabric.
- Avoid the risk of entrapment by using the sofa bed as intended; sitting facing forward on the seat.
- Keep small parts away and out of reach of children and pets.
- Do not allow children to operate the sofa bed mechanism.

PARTS LIST


IMAGE	NAME	PART	QTY	IMAGE	NAME	PART	QTY
	Seat	A	1		Main Leg	I	8
	Chaise	B	1		Support Leg	J	4
	Pop Up Section	C	1		Castor	K	4
	Arm	D	2		Screw	L	16
	Chaise Backrest	E	1		Bracket	M	4
	Seat Backrest	F	1		Screw Driver	N	1
	Back Cushion	G	3				
	Small Cushion	H	8				

ASSEMBLY INSTRUCTIONS

Unpack your sofa bed and check that all the parts on the Parts List are present - these may be in a zip compartment within the base. If any are missing, please contact the retailer from whom you purchased the product. We would advise having 2 people to assemble this product.


STEP 1

Assemble your sofa bed on a flat, soft surface to prevent any damage. Attach the Main Legs (I) to the Chaise Section (B) and Arms (D), then attach the Support Leg (J) to Seat Section (A).



STEP 2

Secure the Castors (K) to the Pop Up Section (C) using the Screws (L) and Screw Driver (N). Insert the Bracket (M) to the Chaise Backrest (E) and Seat Backrest (F).



STEP 3

Attach the Seat Backrest (D) to the Seat (A) and Chaise Backrest (E) to the Chaise (B). Then, carefully guide the Pop Up Section (C) onto its runners.

