ASSEMBLY INSTRUCTION FOR WC-45-7480L-WSR-BW- 75"


Note:

- Read Instructions carefully.
- Carefully identify each component especial those that are similar.
- Separate and identify each component from the hardware pack and rest each one in its proper location before fastening.
- Do not over tighten the screws or bolts when assembling












Assemble the bed frame component and tighten all bolt.




Hook the side rail to bolt as shown and don't tighten the bolt yet.




Put in cross bars and fix in bolt 'N' as shown in diagram and tighten all bolts.



Fix center bar 'F' to cross bar 'G' by follow like diagram as shown.



Fix in support leg with bolt 'M'.



accordingly to the default holes. Ensure the plastic cap's pin is

aimed to the hole. At last make sure all screws and bolts are

tighten.At last fix wood button 'R' as shown.

Please follow our assembly instruction procedure for easier assemble.

PARTS & HARDWARE LIST FOR WC-45-7480L-WSR-BW-75

NO	PART	QTY	NO	PART	QTY
A	HEAD FRAME	1 pc	I	SUPPORT LEG	3 pcs
В	FOOT FRAME	1 pc	J	Double end plastic cap	12 pcs
С	HEAD POST	2 pcs	K	Single end plastic cap	24 pcs
D	FOOT POST	2 pcs	L	M6x80mm	8 pcs
1	at the state of th		М	M8x40mm (assembled)	3 pcs
Е	Side rail	2pcs	N	∭ M6x15mm	8 pcs
F		1pc	0	M8x25mm	12 pcs
	Center bar 25mm x 25mm		Р	Wood Dowel	8 pcs
G	Cross bar	2pcs	Q	M6x30mm	2 pcs
	A		R	Wood Button	8 pcs
Н	Wood slat	24pcs		M6 - ALLEN KEY	1 pc
				M8 - ALLEN KEY	1 pc