





Instructions by Time4Sleep Products

Weston Platform Bed Frame

Assembly instructions for Weston Platform Bed Frame by Time4Sleep

Product Information

Weston Platform Bed Frame



Description

The Weston Platform Bed Frame pairs modern simplicity with practical storage. Its sturdy wooden frame and curved bentwood slats provide reliable mattress support, while two smooth-gliding drawers offer convenient space for bedding and essentials. With its clean lines and low-profile design, the Weston brings both function and style to contemporary bedrooms.

Product specifications

	Double	King
Overall Dimensions (LWH mm)	2020 x 1440 x 335	2120 x 1590 x 335
Interior Dimensions (LW mm)	1930 x 1380	2030x 1530
Distance between slats (mm)	68	68
Slat Dimension (mm)	685 x 53 x 9	760 x 53 x 9

SKU

Wes46Platform, Wes50Platform

Before you start



- Please read this sheet prior to assembly to familiarise yourself with the various stages of construction. Carefully open the pack supplied and check the contents against the parts and fittings check list.
- Do not destroy any of the packaging until you are certain that you have all the necessary parts for the assembly.
- Please ensure that the packaging is disposed of in a safe environmentally friendly way.
- **Caution:** There are small components used in the construction of this unit. These loose items should be kept away from young children during assembly, to avoid danger of choking.

Care & Maintenance

In the unlikely event of missing or damaged parts, please contact your retailer. Please have this guide at hand quoting the part code reference numbers shown when requesting spare or replacement parts.

General Hints & Tips

- Two person assembly
- Please retain your assembly instruction and tools provided for future use. Periodically check that all bolts are still tight.



Tools

Bolt (M8*18mm)

4



Bolt (M8*25mm)

10



Bolt (M8*30mm)

8



Bolt (M8*45mm)

2



Threaded Stud (M8*75mm)

16



Nut For M8 Bolts

16



Half Moon Bracket For M8 Bolts

16



Large Flat Washer For M8 Bolts

24



Small Flat Washer For M8 Bolts

16



Spring Washer For M8 Bolts

40



Wood Screw (Ø4*14mm)

20



Carcass Screw (Ø7*50mm)

40



Wood Dowel (Ø8*30mm)

12



Allen Key for M8 Bolts

1



Allen Key for M6 Bolts

1



Spanner for M8 Nuts

1



Slat End Cap

30



Slat Centre Cap

15




Wheel

10



Parts



1	Headboard/Footboard Panel	2
2	Headboard/Footboard Leg	4
3	Side Rail	2
4	Side Rail Drawer Access Support Leg	4
5	Centre Support Rail	1
6	Support Legs For Centre Support Rail	2
7	Side Rail Cross Bar	1
8	Bentwood Slats	30
9	Drawer Facia Panel	2
10	Drawer Front Panel	2
11	Drawer Side Panel - LH	2
12	Drawer Side Panel - RH	2
13	Drawer Back Panel	2




14	Drawer Base Panel	2
15	Drawer Base Support Rail - Ends	4
16	Drawer Base Suport Rail - Middle	2



Steps (17)



1. Prepare Side Rails with Support Legs




1. Take **two Side Rails (3)** and **four Side Rail Drawer Access Support Legs (4)**.
2. Insert **Wood Dowels (M)** into the predrilled holes on the inner ends of each Side Rail (3).
3. Position the Support Legs (4) against the Side Rails (3).
4. Secure each Support Leg using:
 - **Bolt (C)**
 - **Spring Washer (J)**
 - **Large Flat Washer (H)**
5. Tighten with the **Allen Key (N)**.
6. Repeat for both Side Rails (2× assemblies).

2. Prepare Headboard and Footboard with Legs

1. Insert **Threaded Studs (E)** into the **Headboard/Footboard Legs (2)** (x4).
2. Insert **Wood Dowels (M)** into both **Headboard/Footboard Panels (1)** (x2).
3. Make sure the studs and dowels are firmly seated for later assembly.




3. Attach Legs to Headboard and Footboard




1. Take the **Headboard/Footboard Panels (1)** and **Legs (2)**.
2. Insert the **Threaded Studs (E)** through the predrilled holes of the panels.
3. Position each Leg (2) onto the ends of the panels.
4. Secure each joint using:
 - **Half Moon Bracket (G)**
 - **Spring Washer (J)**
 - **Small Flat Washer (I)**
 - **Nut (F)**
5. Tighten firmly using the **Spanner (P)**.
6. Repeat for both the headboard and the footboard (2× assemblies).

4. Insert Threaded Studs into Panels



1. On both completed **Headboard/Footboard Panels (1)**, insert **Threaded Studs (E)** into the side edges (2 studs on each side).
2. These studs will later connect the side rails to the headboard and footboard.


5. Attach First Side Rail



1. Take one **Side Rail (3)** and align it with the **Headboard/Footboard Panel (1)**.
2. Fit the side rail onto the **Threaded Studs (E)** inserted earlier.
3. Secure the connection with:
 - **Half Moon Bracket (G)**
 - **Spring Washer (J)**
 - **Small Flat Washer (I)**
 - **Nut (F)**
4. Tighten with the **Spanner (P)**.
5. Repeat the process for the opposite side with the second **Side Rail (3)**.




6. Attach Opposite Panel




1. Position the remaining **Headboard/Footboard Panel (1)** to connect with both Side Rails (3).
2. Slide the rails onto the **Threaded Studs (E)**.
3. Secure each joint with:
 - **Half Moon Bracket (G)**
 - **Spring Washer (J)**
 - **Small Flat Washer (I)**
 - **Nut (F)**
4. Tighten firmly with the **Spanner (P)**.
5. At this stage, the bed frame rectangle should be standing.

7. Fit the Side Rail Cross Bar



1. Take the **Side Rail Cross Bar (7)** and place it across the middle of the frame between the **Side Rails (3)**.
2. Secure each end of the Cross Bar using:
 - **Bolt (A)**
 - **Large Flat Washer (H)**
 - **Spring Washer (J)**
3. Tighten using the **Allen Key (N)**.

8. Assemble Centre Support Rail





1. Take the **Centre Support Rail (5)** and position the **Support Legs (6)** underneath at the marked points.
2. Secure each leg with:
 - **Bolt (D)**
 - **Large Flat Washer (H)**
 - **Spring Washer (J)**
3. Tighten firmly with the **Allen Key (N)**.




9. Fit Centre Support Rail to Headboard and Footboard

1. Position the **Centre Support Rail (5)** between the **Headboard and Footboard Panels (1)**.
2. Attach the rail using:
 - **Bolt (B)**
 - **Large Flat Washer (H)**
 - **Spring Washer (J)**
3. Tighten with the **Allen Key (N)**.
4. Before fully tightening, ensure the bed frame is properly squared (check the diagram).
5. Once aligned, tighten all bolts securely to 100%.




10. Assemble Drawer Frames (x2)



1. Take the **Drawer Side Panel – Left (11)**, **Drawer Side Panel – Right (12)**, and the **Drawer Back Panel (13)**.
2. Connect the side panels to the back panel using **Carcass Screws (L)**.
3. Tighten with the **Allen Key (O)**.
4. Repeat to assemble two drawer frames.




11. Fit Drawer Base Panels




1. Take the **Drawer Base Panel (14)** and slide it into the grooves of the **Drawer Side Panels (11, 12)** and **Drawer Back Panel (13)**.
2. Ensure the base fits flush inside the frame.
3. Repeat for both drawers (x2).

12. Attach Drawer Front Panels



1. Position the **Drawer Front Panel (10)** at the open side of the drawer frame.
2. Secure it to the drawer sides using **Carcass Screws (L)**.
3. Tighten with the **Allen Key (O)**.
4. Repeat for both drawers (x2).


13. Attach Drawer Base Support Rails



1. Take two **Drawer Base Support Rails - Ends (15)** and one **Drawer Base Support Rail - Middle (16)**.
2. Position them inside the drawer frame between the front and back panels.
3. Secure each rail using **Carcass Screws (L)**.
4. Tighten with the **Allen Key (O)**.
5. Repeat for both drawers (x2).




14. Fit Wheels to Drawers




1. Turn the drawer upside down.
2. Attach **Wheels (S)** to the corners and the centre support rail ends.
 - Each drawer requires 5 wheels.
3. Secure each wheel with **Wood Screws (K)**.
4. Tighten with a screwdriver.
5. Repeat for both drawers (x2).

15. Attach Drawer Facia Panels



1. Take the **Drawer Front Panel (10)** and the **Drawer Facia Panel (9)**.
2. Insert **Wood Dowels (M)** into the predrilled holes of the facia panel (9).
3. Position the facia against the drawer front (10).
4. Secure using:
 - **Bolt (B)**
 - **Large Flat Washer (H)**
 - **Spring Washer (J)**
5. Tighten with the **Allen Key (N)**.
6. Repeat for both drawers (x2).

16. Install Slats




1. Take the **Bentwood Slats (8)** and fit one **Slat End Cap (Q)** onto each end.
2. Press each slat into place across the bed frame between the side rails.
3. Use **Slat Centre Caps (R)** to join paired slats to the **Centre Support Rail (5)**.
4. Repeat until all slats are installed evenly across the frame.



17. Insert Drawers

1. Slide the completed **drawers** into the openings on both sides of the bed frame.
2. Ensure the **wheels (S)** roll smoothly along the floor and the drawers fit evenly under the bed.
3. Check that both drawers open and close freely.



Need Help? Call 01484 500 560 or email hello@time4sleep.co.uk - please include your order number if you have one!



Instructions by Time4Sleep Products

Weston Platform Bed Frame