

Kensington Bed

ASSEMBLY INSTRUCTIONS

IMPORTANT, KEEP THIS DOCUMENT FOR FUTURE REFERENCE

BEFORE YOU BEGIN ASSEMBLY

PRE-ASSEMBLY:

- Please read all instructions before beginning assembly
- For ease of assembly two people are recommended
- Save all packing materials until assembly is complete to avoid accidentally discarding smaller parts or hardware
- Assemble this furniture on a protective surface, in the room it will be used

CARE INSTRUCTIONS

- To protect the internal wooden frame, it must not be exposed to excessive heat or humidity
- Seek professional help to clean this product in situ

THIS PACK CONTAINS:

YOU MAY NEED: Drill (not supplied)

Fittings suitable for your wall type (not supplied)

PARTS: A: Divan Base x 2

B: Headboard

- C: Baton (attached to the back of H/B)
- D: Linking Brackets x 2

BASE ASSEMBLY

- 1. Remove the bases from their packaging and stand them on their side, placed tightly together. Ensure the side with the Headboard bolts, is nearer the wall.
- 2. Attach the adjacent legs together using the linking brackets provided (one leg from each base).
- 3. Lower the two joined bases carefully onto the floor.
- 4. Then attach the headboard to the base using the bolts provided or, follow the instructions below to attach the headboard to your wall.

TO FIX YOUR HEADBOARD TO THE WALL

- 1. If using wall fixings, measure up from the floor 127cm, draw a horizontal line on the wall the length of the baton (supplied).
- 2. If fitting over a skirting board, a spacer may be required (NOT SUPPLIED).
- 3. Mark and drill holes to match the hole positions on the baton.
- 4. Unscrew the baton from the back of the H/B and attach to the wall using fittings suitable for the wall type.
- 5. Sit the headboard on the baton and gently slide it down onto the baton, adjusting sideways if required. (Fig 1)

TO FIX YOUR HEADBOARD TO THE BED

1. Using the bolts provided with the divan bed, pierce the bolts through the front fabric of the headboard and screw them into the sockets in the divan base.

YOUR BED IS NOW ASSEMBLED

